

The "X" in the part number			COAST/ACM					
refers to the Quality Level	Dimensions are in inches, and			COASTACIN				
	tolerances are:							
(C, B, E, or S), see Quality	Fractions	Decima	ls Angles	TITLE				
Assurance Provisions	$.X = \pm 0.1$ $\pm 1/64$ $.XX = \pm 0.02$ $\pm 5^{\circ}$		Inductor					
above.		.XXX=±0.0	10	FSCM		DWG. NO		REV.
	DRAWN BY		DATE	22558		33040X		
DO NOT SCALE DRAWING	Jim Allen		09/08/03	SCALE: none	MA	X. WT.: 16 grams	SHEET	1 OF 1